

## Sistema di fissaggio per Fiat Panda (PN. 63-FKPANDA)



Il kit è composto da:

- 4 x attacco interno mancorrente
- 2 x contro piastre esterne anteriori
- 2 x contro piastre esterne posteriori
- Portapacchi raccomandato 63-1409

Il kit si monta in circa 1/2 ora

### Istruzioni:

Assemblare gli attacchi interni con le contro piastre esterne direttamente sul mancorrente del veicolo utilizzando i bulloni M6 in dotazione. Il punto esatto di posizionamento sul mancorrente è dato da un riferimento che si trova sulla facciata interna del mancorrente, infatti ci sono 2 forature appena accennate. L'attacco interno mancorrente ha infatti 2 punzonature che copiano perfettamente le forature indicate. Stringere definitivamente l'attacco interno alla contro piastra. Inserire sul lato esterno del portapacchi gli inserti M8 in dotazione (2 per lato).

Posizionare il portapacchi e fissarlo agli attacchi pre-installati usando il bullone a brugola in dotazione.

Una volta fissato il portapacchi, prima di stringere i 4 bulloni a brugola, fare scorrere il portapacchi in avanti o indietro, verificando che non ci sia alcuna interferenza con l'apertura del portellone posteriore e l'antenna radio.

Stringere definitivamente tutti i bulloni.



## Fitting kit for Fiat Panda (PN. 63-FKPANDA)



The kit is composed of:  
4 x inner attachments to the roof-rail  
2 x front outer backplates  
2 x rear outer backplates  
Roof-rack recommended: 63-1409

The kit can be mounted in about half an hour.

### Instructions:

Assembly the inner attachments together with the outer plates directly on the vehicle roof-rail by means of the M6 bolts provided. The exact positioning point on the roof-rail can be found by looking for the 2 holes slightly drilled on the inner face of the roof-rail. The inner attachment to the roof-rail has in fact 2 punched marks that perfectly match the above drilled holes. Finally tighten the inner attachment to the backplate. Insert the M8 inserts provided in the kit on the outer side of the roof-rack (2 inserts per side). Place the roof-rack in position and attach it to the pre-installed attachments by means of the socket head screw provided. Once you have attached the roof-rack, always slide the roof-rack forwards and backwards and check there is no interference in the opening of the rear door and with the antenna. Now, tighten the 4 socket head screws. Finally tighten all the bolts.

